



LEAKTRONICS

ELECTRONIC LEAK DETECTION EQUIPMENT

HydroDome Assembly

1

Install both round and flat gasket on the microphone assembly.



2

Insert the microphone assembly through the hole in the HydroDome and install the other flat gasket on the inside.



3a

Screw-on the end cap which will sandwich the gaskets to the HydroDome.



3b

Note: Only make hand tight. It is unnecessary to use a wrench to tighten.

This is what it should like.



4

Align the pool pole assembly with both brackets and insert screws.



For more information, visit
www.leaktronics.com or call us at 818.436.2953.